

Denim AW-1101 ~ AW-1108

P-COLLECTION

- DO NOT put the goods onto soiled floor.
- DO NOT crease the goods.
- DO NOT get paste on the face of the product.
- Follow the **UP** instruction onto the backside. (DO NOT reverse hang.)
- Hung straight and side match.
- USE soft bristle brush and urethane seam roller. Do not use a metal knife or stiff sweep.
- Hang wallcoverings with pre-trimmed edges on butt-Joints.
This product can be double seam cut on the wall, if necessary.
- Cut with a very sharp, single edge razor blade.
- DO NOT have longer relaxing time. (Usual relaxing time: 5-15 Minutes)
- Wipe off excess paste immediately with soft damp cloth. Do not scrub and rub.

1 General Guidelines

- Ensure that you have received the correct products, all material have same lot number before installation.
- Please inspect the goods for defects carefully prior to installation.
- Product claims will not be considered on cut or installed material after three panels have been installed.
- Seams may be obvious upon installation, this is not considered a defect.
- Do not reverse hang.

2 Wall Preparation

- Ensure surfaces are clean, smooth, dry, firm and uniformly colored.
If not, necessary remedy works are required.
- Walls should be primed with a good quality primer.

3 Installation

- Use a Heavy Duty, Clear, Pre-Mixed, Water-Based Adhesive. Do not dilute the adhesive.
- Apply the paste to the back of the wallcoverings evenly, which will become flexible and easy to hang.
- Do not use too much adhesive to avoid seam tearing stains on the wallcovering.
- Allow to rest 5 to 15 minutes.
- Apply wallcoverings to the wall using a soft bristle nylon brush carefully.
Do not use a metal knife or stiff sweep.
- This design is meant to be straight hung and side matched, due to its pattern.
- Smooth until all air bubbles are removed.
- Trim edges with a very sharp, single edge razor blade. Change your blades often.
- Use a urethane seam roller to set the seams. Avoid over working seams to prevent damage to edges.
- Never allow the adhesive to get on face and/or edges of the material.

4 Cleaning

- Blot excess adhesive, DO NOT rub.
- Dampen the stained area with clean soft cloth soaked with a very mild liquid detergent, if necessary, and dab off it by clear soft dry cloth smoothly.